



NOTE

- (XX) Notations for these references are available in Section 12 of the Alucobond Fixed Cassette System Manual.
- Open drainage joint is only required on highrise buildings at every second floor level. For buildings where the Alucobond wall spans over more than 3 storeys high.

	DRAWING TITLE	NOTES:	DRAWING STATUS	
	15mm OPEN JOINT DETAIL	THIS DRAWING FORMS PART OF AND MUST BE READ WITH THE ALUCOBOND FIXED CASSETTE SYSTEM MANUAL.	ARCHITECTURAL RESOURCE	
			SHEET NO. 03	ROLE C
DRAWN BY: RP		SCALE: 1:2	DATE: MARCH 2013	